

PAR lamps LED digital display instructions

1. LED display window function control table, all the function are selected and than press D key to save confirm.

NO.	Value	Function Description
1	d001 – d512	DMX512 address
2	8CH – 5CH	Dmx channel mode
3	P000 – P255	Discus hopping
4	L000 – L255	Colorful gradient
5	E000 – E255	Colorful clock change
6	S0UD	Colorful voice change, closed light when no sound
7	SUND	Colorful voice change, always open led
8	r000 – r255	Red dimmer: dark - light
9	G000 – G255	Green dimmer: dark - light
10	b000 – b255	Blue dimmer: dark - light
11	W000-W255	White dimmer: dark - light
12	F000 – F255	Strobe

2.DMX512 Channel Description

8CH

NO.	Function	Value	Explain
1	Tatol dimming	000 - 255	Linear dimming from dark to light
2	Strobe	000 - 000	No Strobe
		001 - 009	Close Led
		010 - 255	Strobe slow to fast
3	Macro	000 - 050	No function
		051 - 100	Transition
		101 - 150	Gradient
		151 - 200	Pulse change
		201 - 255	Voice
4	Macro speed	000 - 255	Slow to fast
5	Red dimming	000 - 255	Linear dimming from dark to light
6	Green dimming	000 - 255	Linear dimming from dark to light
7	Blue dimming	000 - 255	Linear dimming from dark to light
8	White dimming	000 - 255	Linear dimming from dark to light

5CH

NO.	Function	Value	Explain
1	Strobe	000 - 000	No Strobe
		001 - 009	Close Led
		010 - 255	Strobe slow to fast
2	Red dimming	000 - 255	Linear dimming from dark to light
3	Green dimming	000 - 255	Linear dimming from dark to light
4	Blue dimming	000 - 255	Linear dimming from dark to light
5	White dimming	000 - 255	Linear dimming from dark to light

